

INSTALLATION INSTRUCTIONS


TWO-HANDLES LAVATORY FAUCET


雙把手檯面龍頭安裝說明

PATENT NUMBER: 專利號碼 001018899-0001 001018899-0003 D 129782









CAUTION: Risk Of Product Damage.

注意:爲增加產品使用壽命,請依說明清潔供水管路

- a./ Turn the angle stops (water suppliers) on and run for 1 minute before connect supply hose (flexible hose) to faucet body. or b./ 安装編織管之前,先把供水開關全開排水一分鐘。或 b./
- b./ Connect and tighten the faucet and angle stops with supply hose (flexible hose) to finish installation, then remove the aerator, fully turn on the hot and cold water valves on faucet and run for 1 minute, then turn off the water and reinstall the aerator. 把龍頭、供水開關及編織管接好並鎖緊之後,把起泡器移開,把熱水及冷水全部轉開一分鐘,然後把水關掉再把起泡器裝回去。

1. Screw Flexible Hoses and Mounting Bolt into Faucet Body (with gasket), insert Flexible Hoses and Mounting Bolt through basin hole in fixture. Place Bracket (with Braket Washer) and Nut onto Mounting Bolt, position faucet on fixture, then tighten Nut securely, meanwhile, assemble Lift Rod (option) with Faucet Body. (Fig.1)

將冷熱進水不銹鋼軟管和金屬牙條鎖緊固定於龍頭本體,再將冷熱進水不銹鋼軟管和金屬牙條穿過洗臉盆(檯)洞口。 從金屬牙條下方依序套入橡皮墊片、金屬固定片、和螺帽,確認 龍頭方向位置後,鎖緊螺帽固定龍頭即可。 同時,把拉桿(選擇性零件)裝在龍頭本體上。(Fig.1)

2. Disassemble Handles with Hexagon Key, and remove Flange from Valves before installing. Insert Valves from underside through the holes of Deck and fasten Flange, then align Valves so that the tee ends(outlet) face to Spout and secure Valves by tightening Lock-Nuts. (Fig.2)

如Fig.2 所示安裝前用六角扳手將把手拆下,並且從閱體上將法蘭蓋拆下,把閱體從檯面下方穿過孔並且鎖上法蘭蓋,然後將閱體的出水口端面向出水口並用固定螺帽鎖緊閱體。

- 3. Ensure that **Handles** are properly aligned and **Valves** are in closed position, then tighten **Set screw** and insert **Cover**. (Fig.3) 確定閥體開關都是關閉的並且把手都有對齊,然後鎖緊埋頭螺絲,並且置入裝飾蓋。(Fig.3)
- 4. Install Connector with filter onto the outlet of Angle Stop first, then connect Flexible Hoses from Valves to Spout and Connector with filter. 先連接過濾接頭到進水開關,然後連接不銹鋼軟管從閥體到出水口及過濾接頭。(Fig.4)

FIXING CONTENTS

組配件內容

